Important Design Parameters

Allowances must be made for air venting. The under slung compressor must have an unrestricted air flow. Proper venting must be provided ensuring cool air from the room can be drawn in through the condensing coil and out the other side.

